



How to Update your LabRadar Firmware to FWA 2.0.0, FWB 2.0.0

- **Using a SDHC card, 32 GB or less, formatted FAT32, erase the card.**
(If needed, do a quick or full format using FAT32, for Mac users choose MS-DOS)
 - Go to: <https://mylabradar.com/download/>
 - Open the firmware link **FIRMWARE V2.0 - Labradar (English)**
 - Open the folder **FIRMWARE 2.0.0.zip**
 - The zip file contains 2 files : **FWA.bin** and **FWB.bin**
(On a MAC computer you will see zippers on the files, do not open these or extract/unzip any further)
- **Copy and Paste the FWA.bin and FWB.bin files to the empty SD card**
- **Insert the card into the LabRadar**
- **Turn on LabRadar**
- Your Labradar will update automatically at startup, the display will briefly show the FWA as 2.0.0 and FWB as 2.0.0, HW: 1.3.0
(Hardware version is subject to change depending on your current device)

Now enjoy your updated product!

The Labradar Team